

## TECHNICAL NOTE# 114 MANUALLY DELETING OLD PROJECT FILES

This technical note will explain how to manually delete old project files off your ET5x00LX unit.

Attach a keyboard to unit.

Power up unit, and allow it to boot your application, or have unit in 'download mode'

1. Type **Ctrl-Alt-F2**
2. Press **Enter**
3. Type **cd \$EASONBINDIR**

Now at this point you can type three different commands to clean off files:

<b>./cleanprogramfiles</b>	Cleans off old program files, graphics
<b>./cleanrecipefiles</b>	Cleans off old recipe files
<b>./cleannonvolfiles</b>	Cleans off old non-volatile files, arrays, data acquisition files

4. Type **Ctrl-Alt-F3** to return back to your program or download mode.