

**TCVR3 INSTALLATION
INSTRUCTIONS****SHIP KIT:**

5 – TCVR3 Tear Away Protective Coverings (20-00514-01)

INSTALLATION:

1. Clean the display area of the Eason unit with a static-free cleaner. Such as Plast-N-Glas. Avoid use of standard cleaners like Windex, or rubbing alcohol as these will cloud the touch screen display.
2. Verify that there is no debris on the display area.
3. Remove the backing material from the TCVR3.
4. Place the starting edge of the TCVR3 (side without the removal tab) onto a short edge of the display area. Either edge will work fine, and will solely determine the position of the removal tab.
5. Working from the starting edge toward the removal tab edge, firmly adhere the TCVR3 to the display area. Avoid leaving air bubbles behind the TCVR3 as these can cause the TCVR3 to prematurely tear. Note: In case of misalignment, the TCVR3 may be applied multiple times within the first 5 minutes of removal from backing.
6. When changing is needed, carefully pull on the removal tab to begin lifting the corner of the TCVR3.

