

---

## **AROMAT PLC NETWORKING AND 2000 FAMILY PRODUCTS**

The Aromat PLC driver in the 2000 Family (WinBuild 2000) supports the use of Linked Registers and Linked Contacts.

These linked registers and contacts are available as data types under the "Address" box when setting up your registers. (Under SETUP | REGISTERS)

Link register addresses LD0 to LD255 are supported, and L0 to L127F link relays are supported.

When these addresses are specified, these data types link you to the remote PLC data that you have mapped into the 'host' PLC that the Eason unit is connected to.