

APPLICATION

The customer needed a bright, color operator interface for their welding operation controlled by a Galil DMC 1520. The Eason 2550 with a color touch screen offered the ability to interface with the Galil, and display operation parameters on screen. The 2550 also provided the ability to choose part numbers from a recipe selection and download those parameters to the Galil.

COLOR OPERATOR INTERFACE WITH TOUCHSCREEN

The bright color display on the 2550 allowed the customer to display their company logo on the start up screen, as well as place LARGE position and part numbers prominently on the display while the machine is running. This helped to reduce operator error, and allowed the operator to quickly check the status of the machine even from a distance.

PART PARAMETER STORAGE

The 2550's recipe management system gave the ability to store part information, so that the operator can select a part name/number, and then have that information downloaded to the Galil. New parts (recipes) can be added either at the terminal, or remotely on a PC and synchronized for back-up.

